

Compatible Cameras:

Brand	Model	Shooting Control via the P1 Gimbal	Compatible Lenses
Sony	Rx100 Series	Video Recording Auto Focus Electronic Zoom	×
	A7 Series A6 Series A5 Series		Sonnar T*FE 35MM FE 28-70mm F3.5-5.6 FE 28mm E 35mm F1.8 OSS E 20mm F2.8 APS-C E 16mm F2.8 APS-C E 10-18mm F4 OSS ASPC FE 50mm F2.8 FE 28mm F2 FE 50mm F1.8 FE 35mm F1.8 Sigma 16mm F1.4 ※Compatible with lenses lighter than 290g/0.64lbs and smaller than 72.5×83mm / 2.85×3.27inches
Panasonic	GH Series	Photograph Video Recording Auto Focus	H-X015GK/GKC H-H020AGK/AGKC H-H025GK H-X025GK/GKC H-F008GK/GKC
	G Series GX Series GF Series	\	
Fujifilm	X-H1 X-Pro2 X-T3	Photograph Video Recording Auto Focus	XF 16mm F2.8 XF 14mm F2.8 XF 18mm F2 XC 15-45mm F3.5-5.6
Olympus	E-M1 Mark II E-M5 Mark III (The FUJI 2.5 camera cable is required for connection.)	Photograph Auto Focus	12mm F2 17mm F1.8 25mm F1.8 9-19mm F4-5.6 12-50mm F3.5-6.3 12-42mm F3.5-5.6 EZ 12-42mm F3.5-5.6 II R
	E-M5 Mark II E-M10 Mark II PEN-F		
	E-PL9 E-M10 Mark III	\	
Canon	EOS M6 EOS M50 EOS M100	\	EF-M 11-22mm f/4-5.6 IS STM EF-M 15-45mm f/3.5-6.3 IS STM EF-M 22mm f/2 STM

Note:

To control camera shooting via the Gimbal, connect a camera and the Gimbal with camera cables then power up the Gimbal before turning on the camera.

1. Electronic Zoom is unavailable for some Sony camera models.
2. The form will be updated without prior notice when the firmware releases.
3. The camera models not listed will be added based on the market feedback.
4. Please note that camera manufacturers will limit access to some functions for their launched cameras, therefore, some models of the series included in the Compatible Camera List might be unable to perform camera functions via the Gimbal when connected with the camera cables.

P1相机兼容列表：

品牌	相机型号	手柄控制功能	可搭载镜头
Sony	Rx100黑卡系列	录像 自动对焦 电子变焦	×
	A7 系列 A6 系列 A5 系列		Sonnar T*FE 35MM FE 28-70mm F3.5-5.6 FE 28mm E 35mm F1.8 OSS E 20mm F2.8 APS-C E 16mm F2.8 APS-C E 10-18mm F4 OSS ASPC FE 50mm F2.8 FE 28mm F2 FE 50mm F1.8 FE 35mm F1.8 Sigma 16mm F1.4 ※镜头重量小于290g, 体积 小于72.5x83mm都可支持。
Panasonic	GH系列	拍照 录像 自动对焦	H-X015GK/GKC H-H020AGK/AGKC H-H025GK H-X025GK/GKC H-F008GK/GKC
	G系列 GX系列 GF系列	\	
Fujifilm	X-H1 X-T3 X-Pro2	拍照 录像 自动对焦	XF 16mm F2.8 XF 14mm F2.8 XF 18mm F2 XC 15-45mm F3.5-5.6
Olympus	E-M1 Mark II E-M5 MarkIII (使用Fuji 2.5连接线)	拍照 自动对焦	12mm F2 17mm F1.8 25mm F1.8 9-19mm F4-5.6 12-50mm F3.5-6.3 12-42mm F3.5-5.6 EZ 12-42mm F3.5-5.6 II R
	E-M5 Mark II E-M10 Mark II PEN-F		
	E-PL9 E-M10 MarkIII	\	
Canon	EOS M6 EOS M50 EOS M100	\	EF-M 11-22mm f/4-5.6 IS STM EF-M 15-45mm f/3.5-6.3 IS STM EF-M 22mm f/2 STM

注意：请先连接好相机控制线开启稳定器后再打开相机，否则有些机型无法进入受控状态。

- 1、SONY部分型号相机不支持电子变焦。
- 2、本表格会随固件发布实时更新，如有变动恕不另行通知。
- 3、未列入表中的相机型号，后续会根据市场反馈进行适配。
- 4、因相机厂商对发布的型号有做功能限制，故可能会出现有些细分型号不支持相机控制功能。